Installation Guide

2016-2026 Titan / Maxima / Pathfinder
2020-2026 Frontier / 2015-2024 Murano
2013-2018 Altima | 2019-2024 Infiniti QX60
KLEINN SKU # - RSNIS4 (HCX)

Years	Nissan (Push-to-Start)													
2013-2018	Altima	13	14	15	16	17	18							
2020-2026	Frontier								20	21	22	23	24	25	26
2016-2023	Maxima				16	17	18	19	20	21	22	23			
2015-2024	Murano			15	16	17	18	19	20	21	22	23	24		
2013-2020	Pathfinder	13	14	15	16	17	18	19	20						
2016-2023	Titan Gas & Diesel				16	17	18	19	20	21	22	23			
Years	Infiniti (Push-to-Start)													
2014-2020	QX60		14	15	16	17	18	19	20						

***Compatible with automatic transmission vehicles manufactured for sale in the US and Canada Only**

Introduction:

This guide covers multiple models that all have the same connectors. There are 2 T-Harness connections required. The first connection is on the drivers side at the OBD II port, the other is located behind the glove box.

- **Pre-flashed Module:** The correct firmware is installed on the remote start module. No programmer needed.
- **Activation**: Press the OEM Remote buttons Lock - Unlock - Lock to remote start the vehicle.
- **Each Vehicles Connection Location Images** Step 1 **Pages 2-8**
- **System Wiring Overview for Frontier, Titan, Pathfinder, and QX60** Step 2 **Page 9**
- **One Wire to Wire Connection for Frontier, Titan, Pathfinder, and QX60** Step 2.1 **Page 10**
- **System Wiring Overview for Altima, Maxima, Murano** Step 2.2 **Page 11**
- **Programming:** Program the module to the vehicle, no PC or Flasher required. Step 3 **Page 12**
- **Vehicle Take Over Procedure:** Step 4 **Page 13**

Remote Start Activation from OEM Transmitter:

Remote Starter Activation: Press Lock>Lock>Lock on your OEM remote to start the vehicle.



Check out our extended range RF Remote or Smartphone Control upgrade kits

Click Here for Upgrade Options

Parts Required:

- Idatalink HCX Module Pre-Flashed with (RSA-NI3)
- T-Harness HCX-NI3

Disclaimer:

Neither the manufacturer nor the distributor of these components are responsible for damages of any kind either indirectly or directly caused by the components, except for the replacement of the components in case of manufacturing defects. This guide is subject to change without notice. Refresh your browser cache or use different browser (Edge, Chrome, Firefox, etc.) to view the latest update.

- **Firmware pre-loaded:** As part of the service Kleinn provides, we have already flashed the compatible firmware version and options into your **HCX** module for you so you are ready to begin the installation in the vehicle.
- You will need to program the module to the vehicle when the installation is complete using Step 3.



Installation Overview

There are 5 basic steps to this remote start installation:

1. Preparation
2. Wiring
3. Programming
4. Testing the system
5. Finishing up!

STEP 1: Preparation

This remote start kit is a **SEMI PLUG & PLAY INSTALLATION TYPE** utilizing custom T-Harnesses which eliminate all but 1 "wire-to-wire" connection. The physical attachment of this product will require only plug-in connections with the exception of Titan, Pathfinder, Frontier, and QX60 that all require 1 connection from a loose purple wire on our t-harness to a blue wire pointed out in step 2.1. Simply plug the T-Harness into the vehicle, make 1 wire connection, then program the module in the vehicle and the remote starter will be ready for use.

- Any vehicle panels required to gain access to the needed plugs outlined in this Tip Sheet will need to be removed. The bulk of the installation typically takes place in the driver's side under dash area. You may need to access the passenger side under dash area for some vehicles. Refer to the Wire Diagram for the locations that need to be accessed in the vehicle. Remember the order that you remove the panels.
- Wait to mount the remote start component(s) in the vehicle until after you have completed the wiring and have tested the system. Keep in mind where you plan to mount the component(s) when routing your wires to avoid having to unplug after programming. The component(s) can be mounted to a rigid wire bundle under the dash using zip ties. Look for an open and convenient location in the vehicle that will fit the component(s). Pay attention to moving parts like the pedals, e-brake and steering column. Be sure to route your wiring away from those areas. It is best to route your wires along with the vehicles factory wires, as this is typically a safe location and it keeps the install neat.
- If your T-harness has loose wires with no plugs at the end they will not be needed for standard installation in this application. Tape up any extra wires or tuck them away with the T-harness and isolate them so they are not in the way. Adding options may require additional wiring connections.

Making Optional Wire-to-Wire Connections

Strip - Poke - Wrap and Tape method is the strongest wire connection that you can make. You MUST use this method for any data wire connection(s). T-Taps should never be used on data connections. If required for your installation, data connections may be labeled: CAN HIGH, CAN LOW. Do not solder wires unless you have experience to prevent causing damage.

Click here for directions on how to Strip/Poke/Wrap/Tape the wires

The recommended Strip - Poke - Wrap and Tape method shown above is the most reliable for remote start installations. Your kit may include T-Tap connectors that can make your connections easier, and still perform reliably when used correctly. T-taps can be used on any connections except for the Data wire connection(s).

Click here for directions on how to use a T-Tap

Locations



Body Control Module (BCM) - Behind Instrument Cluster



OBD2 Port - Bottom Edge of Dash



Locations

Body Control Module (BCM) - Above Gas Pedal





OBD2 Port - Bottom Edge of Dash



Locations



Body Control Module (BCM) - Behind Instrument Cluster



OBD2 Port - Bottom Edge of Dash



Pathfinder Connection Locations

Locations



Body Control Module (BCM) - Behind Instrument Cluster





OBD2 Port - Bottom Edge of Dash

Locations

Body Control Module (BCM) - Above Gas Pedal





OBD2 Port - Bottom Edge of Dash



Locations



Body Control Module (BCM) - Behind Instrument Cluster



OBD2 Port - Bottom Edge of Dash



Optional Power Liftgate Control - Left of Steering Wheel



STEP 2: Wiring Diagram Frontier, Titan, Pathfinder, QX60



Squeeze locking tabs on sides of OBD2 port to remove it from location in vehicle. Plug port into VS1 on the harness place VS2 back into the original OBD2 port location.

STEP 2.1: Accessory 2 Connection Frontier, Titan, Pathfinder, QX60

Please Note: This connection is only required on the Frontier, Titan, Pathfinder, and QX60,.

Accessory 2 Connection



Connect the loose Purple wire from the T-Harness to the Blue wire in Pin 9 of the 24 pin Black connector.

STEP 2.2: Wrring Diagram Murano, Maxima, Altima



Squeeze locking tabs on sides of OBD2 port to remove it from location in vehicle. Plug port into VS1 on the harness place VS2 back into the original OBD2 port location.

STEP 3: Programming the Module in the Vehicle

Your Remote Start module now needs to be paired to your vehicle. Before starting the programming sequence, make sure that all of the connectors are plugged into the module. Instructions for programming the Remote Start are below. Follow the programming instructions for the LED1 and LED2 descriptions to monitor flashes.



Program the Remote Start Module

With the module connected as shown in the wiring diagram, begin the programming procedure outlined below.

01 

Push start button twice [2x] to ON position.

02 
Wait, LED 1 will turn solid GREEN for 2 seconds.



03 

Push start button once [1x] to OFF position.

04 

START vehicle for and allow it to idle for about 15 seconds.

05 
Press and hold the brake pedal.

06 
Press and release the module's programming button.



07 
Release the brake pedal.

08 
Wait, LED 2 will flash GREEN twice (2x) and then turn off.



09 
Module Programming Procedure completed.

STEP 4: Finishing up!

After confirming that everything works properly, cap off or tape the ends of any wires you're not using to avoid grounding or other contacts.

- Now gather up all the wiring and neatly bundle it together using zip ties or electrical tape to prevent the wires from interfering with any of the moving parts under the dash.
- Test the system often when you are putting your vehicle back together.
- Find a secure place to put the remote start module and use zip ties to secure it. Be careful not to zip tie near your connections as it may create a bad connection.
- Replace any interior vehicle panels that were removed to gain access to the needed wires, in reverse order that they were removed.
- Test the system as you reinstall the panels in your vehicle to make sure you do not pull something loose or pinch a wire. Be careful not to run a screw through a wire or pinch a wire while reinstalling panels.
- If your test was unsuccessful, go back and re-check your wiring and programming. If you used any T-Taps, make sure they are all attached correctly. Poorly made T-Tap connections are the #1 cause for tech support calls. Also, remember that T-Taps should never be used on data connections.

VEHICLE TAKE OVER PROCEDURE

This system will run for 15 minutes, then turn off on its own. You can restart it one more time before you have to enter the vehicle resetting the system. If you approach the vehicle while it is still running, unlock the doors, enter the vehicle with the OEM key, close the door, press the brake for about 3 seconds, you will hear a click from the remote starter turning off and you can drive away.

TAKEOVER PROCEDURE - 1 OF 1

01 
All vehicle doors must be closed and locked prior to remote start sequence.

02 

Press the Lock button 3 times on the vehicles OEM factory remote.

03 
The vehicle engine will start.

04 
Press unlock on the OEM remote or request switch.

Enter the vehicle with the OEM keyfob and close the door.

05 
Time rescriction. Complete Step 6 within 45 seconds of unlocking the vehicle.

06 
Press the BRAKE pedal for about 3 seconds and release.

07 
The vehicle can now be put in to gear and driven..

>> 
failure to follow procedure will result in no take over and vehicle engine will shutdown.

If you have any installation questions or problems, you can create a support ticket for help at:
install.kleinn.com/support

Kleinn Automotive Accessories
520-579-1531

Copyright 2026 Kleinn Automotive Accessories

Troubleshooting Charts

When the system receives an activation command and you hear clicks from the HCX remote start module brain but the vehicle fails to start, Parking lights flash and HCX brain will click 3x times followed by a number of flashes and clicks for the diagnostics code. The second number of flashes/clicks corresponds to a remote start diagnostic error code. This will tell you why the remote starter is failing to start. The codes are as follows:

REMOTE STARTER ERROR CODES: NOTES	PARKING LIGHT FLASHES	DIAGNOSTIC
I WARNING: The following applies only when the parking lights are connected and supported by the system. II After a remote starter failure, the parking lights will flash three [3x] times followed by the error code. See table.	3 + 1	Tach is not programmed OR engine is already running.
	3 + 2	Key is in ignition ON position.
	3 + 3	Door is open.
	3 + 4	Trunk is open.
	3 + 5	Foot brake is ON.
	3 + 6	Hood is open.
	3 + 7	Loop is not cut.
	3 + 8	Vehicle failed to remote start.
	3 + 9	Vehicle movement detected (VSS).
	3 + 10	System is in Valet Mode.
	3 + 11	CAN communication failure
	3 + 12	RS not synchronized. Start vehicle with OEM key for 15 sec before trying a new RS sequence.
	3 + 13	Bypass problem.
	3 + 14	Idle mode or takeover is not available on this vehicle.
	3 + 15	Overheat protection.

REMOTE STARTER SHUTDOWN ERROR CODES: NOTES	PARKING LIGHT FLASHES	DIAGNOSTIC
I WARNING: The following applies only when the parking lights are connected and supported by the system. II If the engine shuts down after a remote starter sequence use the query command from a compatible aftermarket remote to display the shutdown error code. The parking lights will flash four [4x] times followed by the error code. See table.	4 + 1	Engine tach signal was lost.
	4 + 2	Emergency brake signal was lost.
	4 + 3	Foot brake ON detected.
	4 + 4	Hood open detected.
	4 + 5	Tach over rev detected.
	4 + 6	Glow plug timeout error.
	4 + 7	Vehicle movement detected (VSS).
	4 + 8	Check engine light ON.
	4 + 9	Low fuel level.
	4 + 10	Open door detected.
	4 + 11	CAN communication failure during RS sequence.
	4 + 12	RS not synchronized. Start vehicle with OEM key for 15 sec before trying a new RS sequence.
	4 + 13	Bypass problem.
	4 + 14	Idle mode or takeover is not available on this vehicle.
	4 + 15	Overheat protection.

MODULE STATUS DURING:	 LED 2*	LED 1**	LED STATUS	DIAGNOSTIC
REMOTE START SEQUENCE	●		Flashing rapid RED	Remote start shutdown sequence.
	●		Flashing slow RED	Remote start shutdown error code. Contact technical support.
	●		Solid RED	Remote start crank delay.
	●		Flashing rapid GREEN	Remote start cycle in progress. Working correctly.
	●		1 GREEN flash	Remote start initiated successfully.
	●		3 GREEN flashes	Idle mode cycle in progress.
	●		4 GREEN flashes	Turbo mode cycle in progress.
		●	Flashing GREEN	Remote start cycle in progress. Displays vehicle platform during runtime.
		●	Rapid GREEN flashing	Secure takeover initiated. Waiting to complete takeover after brake press.
TRANSMITTER PROGRAMMING	●		Solid RED	Remote programming in progress, waiting for remote pairing.
	●		1 GREEN flash	Remote programmed.
	●		4 RED flashes	Shutdown remote starter before attempting remote programming.
	●		5 RED flashes	Engine must be off before attempting remote programming.
	●		6 RED flashes	System must be unlocked/disarmed before attempting remote programming.
	●		7 RED flashes	Module must be learned to the vehicle before attempting remote programming.

* LED 2 (RS) displays generic diagnostic codes specific to the remote start module. Orange LED flashes may appear red.
** LED 1 (Bypass) displays diagnostic codes specific to the firmware loaded on the module.
Visit the programming diagnostics page for more information.